2. Disassembly and Reassembly

2-1 Front Cabinet

1. Remove the Lid battery of A
2. Remove 9 screws of ① of its rear part
3. Remove 3 screws of ② of its rear part
4. Remove Front/Top Cabinet of B



Fig 2-1

2-2 Top Cabinet

1. Remove Top Cabinet of C to topward.



Fig 2-2